

# BIG SIX SUPER SPIN

---

Description

## CONTENTS

<b>BASIC STRUCTURE</b>	<b>3</b>
<b>INTERBLOCK'S BIG SIX SUPER SPIN</b>	<b>4</b>
<b>BIG SIX SUPER SPIN INTERFLEX GUI</b>	<b>5</b>
<b>GAME FLOW</b>	<b>7</b>
<b>PAYTABLES</b>	<b>7</b>

## BASIC STRUCTURE

The central module of the Big Six Wheel is an automatic Wheel generator, which is equipped with one big rotating wheel, detection devices and electromechanical spinning mechanisms (in short, the electronic Big Six Wheel Generator). It is fastened to the top of a metal frame cabinet containing a PC, electrical supply devices and devices control board.

- 1 Big mechanical wheel**  
Wheel is divided into 54 equally separated segments. Each segment is associated with a symbol.
- 2 Super Spin Wheel**  
Super Spin LED display.
- 3 Electrical cabinet**  
This part contains a PC and the electrical wiring needed to operate the generator and run the game.



## INTERBLOCK'S BIG SIX SUPER SPIN

The Diamond Big Six Super Spin is Interblock's version of the classic Big Six wheel game. It is **fully automated**, so operators don't have the overhead costs usually associated with this classic game of chance. The LED display in the middle for the second wheel, called Super Spin, makes this classic casino game even more attractive for players.

Big Six Super Spin is a **double-sided wheel**, with stations placed on one or both sides. Because it is a **standalone unit**, the Play Stations can be placed in **different configurations and arrangements**, not necessarily in the nearby area.

The Big Six Wheel generator consists of one big vertical mechanical wheel, divided into **54 compartments**. 50 compartments are associated with a number. The numbers on the wheel are graphical representations of the results produced by the random number generator. The other four compartments **have higher payouts**. The payout is not predetermined because it is set by one of five available pay tables.

Big Six Super Spin wheel generator actually serves as an **analog display of gaming results**. The automated wheel is controlled by the embedded PC with gaming software installed.

The player places a wager on one or more of the numbers or on one of the bonus bets. Please note that in some cases, the Super Spin Special bet is only available if accompanied with a base bet, which is a bet on one of the numbers. If the wheel pointer stops on the selected number/symbol, the player wins. The Big Six Super Spin game includes a feature where the **player with the highest bet** can initiate stopping of the wheel after the "Last bets" sign.

The Big Six Super Spin employs **mechanisms**, e.g. as multiple

various **anti-tamper** access sensors & switches.



### BIG SIX SUPER SPIN INTERFLEX GUI



- 1 Cashout, credit, credits opacity**
  - **Cashout:** When no bets are on the table, pressing this button will pay out the player’s credit via the ticket printer or it will initiate a hand-pay, if the credit exceeds the limit for ticket payouts.
  - **Credit:** Displays the total of the player’s credits, this value is always displayed in currency, never in chips.
  - **Credits opacity (button):** This button is used to reduce the visibility of the player’s credits and his last bets, wins and the playable amount.
  
- 2 Main information display**

In this window the player receives information on when to start placing bets and when to revise the numbers called in the previous game. This window also displays messages about errors that may occur on the Play Station.
  
- 3 Interface controls**
  - **Tip:** Sends a tip to the attendant.
  - **Call attendant:** Signals the attendant of the gaming device and/or entering into Operator menu.
  - **Flags:** Changes the language of the entire player’s interface to the language of the highlighted flag.
  - **Sound:** Controls the sound volume of the game. The system will automatically divide the maximum set volume across the 3 available levels.
  - **Options menu:**
    - **Show Winnings (optional):** As the user places his bets, the possible winnings are displayed for each bet, if that number is drawn. Possible winnings display is enabled or disabled by moving the slider.
    - **Reserve Table (optional):** Enabling the option allows player to reserve a Play Station for a short time.
    - **Values In:** This option allows the player to toggle between showing a currency format or a credits format for the playable credit information, current bet, last bet and last win.
  - **Help/Rules:** Displays the help screen.

- 4 Betting information**

This information can be made less visible by using the brightness button next to the amount of credits available.

  - **Last Win:** Displays the amount won in the previous game.
  - **Playable:** Displays the amount available for betting.
  - **Bet:** Displays the amount currently wagered on the table.
  - **Last Bet:** Displays the last bet
- 5 Super Spin Special bet**

The Super Spin Bet betting position can be configured as a special bet. This is done in the InitialValues settings software.
- 6 Betting layout**

Includes 7 or 8 betting positions. Each betting field also displays the winning odds.
- 7 History bar**

Displaying last 25 results.
- 8 Denomination button**

With this, you can set the value of one credit and hence the value of the game. The selected value of one credit is displayed on the denomination button.
- 9 Game controls and chips**
  - **Clear last bet/Clear all bets:** Clears the last bet from the table. If pressed twice, all bets will be cleared from the table.
  - **Double bet:** Doubles all bets on the table. If doubling all bets exceeds the player's playable credit, only the first few bets will be doubled until the playable credit limit is reached.
  - **Repeat last bet:** When this button is pressed after the end of the game, it will repeat the bet from the previous game. This button can be set to auto repeat, if pressed for more than 3 seconds and confirming that decision. When the game runs from the Internal RNG, we offer an additional Keep Bets On setting, which places the bets back on the betting field automatically, but does not start a new game cycle. This setting may be subject to jurisdictional rules.
  - **Chips:** 4 chips, each with a different value that the player can select and place on the table. Values assigned to chips are defined with the selected denomination.
- 10 Spin button (optional)**

The game begins when the player presses Spin button. This button is visible when the game is running internally.
- 11 Game time counter**

A timer which show how much time is left until the game begins. Players can place bets until the timer runs out.

### GAME FLOW

The object of the game is to predict on which symbol the rotating wheel will stop. Before each spin, the player can place a wager on one or more number/symbols.

If the player places a wager on the bonus number/symbol and the number/symbol wins, the inner (virtual) Bonus wheel spins. The Bonus wheel is divided into equal segments. Each segment is associated with a multiplier value, which multiplies the wager placed on the bonus symbol. The probability for each number/symbol to be selected isn't a constant, but it's weighted randomly; meaning that some numbers have a higher chance of being selected than others.

**NOTE:** A bet on the bonus symbol is allowed only if it's accompanied with a bet on at least one other symbol (in case Super Spin is configured as a special bet). Bet on the bonus symbol must be lower or equal than the sum of bets on other symbols (only applicable for Pay table 104,69).

When the game ends, the timer on the top left side shows the time remaining (in seconds) until the next spin, during which the players can place their wagers. The wheels starts spinning after the betting time is over.



The wheel can be stopped by the highest betting player directly after the game timer runs out. The time at which the wheel is stopped will not affect the outcome of the game. If other players match the highest total bet, the player who first placed it keeps the right to stop the wheel. If the original highest betting player withdraws, the chance to stop the wheel is passed on to the player who matched the highest bet and has the lowest player ID number.



## PAYTABLES

*Big Six Super Spin – main game pay table*

Paytable	1	3	5	11	23	Black Diamond	Red Diamond	Super Spin
EL1514	1:1	3:1	5:1	11:1	23:1	47:1	47:1	*
EL1515	1:1	3:1	5:1	11:1	23:1	46:1	46:1	*
EL1516	1:1	3:1	5:1	11:1	23:1	45:1	45:1	*
EL1517	1:1	3:1	5:1	11:1	23:1	44:1	44:1	*

*Super Spin special bet – pay table*

Pay table 76			Pay table 77			Pay table 78			Pay table 79		
Symbol	Weight	Pays	Symbol	Weight	Pays	Symbol	Weight	Pays	Symbol	Weight	Pays
x 1000	1	1000:1	x 1000	1	1000:1	x 1000	1	1000:1	x 1000	1	1000:1
x 500	2	500:1	x 500	2	500:1	x 500	2	500:1	x 500	2	500:1
x 100	3	100:1	x 100	3	100:1	x 100	3	100:1	x 100	3	100:1
x 75	5	75:1	x 75	5	75:1	x 75	5	75:1	x 75	5	75:1
x 50	10	50:1	x 50	10	50:1	x 50	10	50:1	x 50	10	50:1
x 20	750	20:1	x 20	650	20:1	x 20	600	20:1	x 20	500	20:1

Pay table 80		
Symbol	Weight	Pays
x 1000	1	1000:1
x 500	1	500:1
x 100	3	100:1
x 75	5	75:1
x 50	6	50:1
x 25	900	25:1

Pay table 125		
Symbol	Weight	Pays
x 1000	1	1000:1
x 750	1	750:1
x 500	2	500:1
x 250	2	250:1
x 100	20	100:1
x 75	30	75:1
x 50	40	50:1
x 25	50	25:1
x 20	100	20:1
x 15	150	15:1
x 10	150	10:1
x 5	195	5:1



Document version:	1.0.1
Document date:	March 1, 2024

Document Revisions	
1.0	Initial document
1.0.1	Special Washington version where “side bet” is replaced with “special bet”, updated addresses and disclaimer, rearranged versioning table, contacts and disclaimer to match newer document style (PI-3432)

Copyright © 2024 Interblock d.o.o. All rights reserved.

The information in this document is confidential.

Reproduction in whole or in part on any medium without the express permission of Interblock d.o.o. is strictly prohibited.

## CONTACTS

### 24/7 technical support

Phone:

USA, Canada, Latin America, Asia-Pacific: +1 877 676 7711

Europe, Middle East and Africa: +386 51 305 111

Fax: +386 1 724 77 44

Email: [call.center@interblockgaming.com](mailto:call.center@interblockgaming.com)

[www.interblockgaming.com/service](http://www.interblockgaming.com/service)

### Regional offices:

#### Australia

INTERBLOCK ASIA & PACIFIC Pty Ltd  
Address: 'World Square Tower' Suite 4555 Level 45,  
680 George Street, SYDNEY NSW 2000

#### Canada

INTERBLOCK CANADA Inc.  
Address: #225 - 20316 56 Avenue, Langley, British  
Columbia, Canada V3A 3Y7

#### Asia

INTERBLOCK ASIA PACIFIC Pty Ltd – Macau Branch  
Address: Avenida da Praia Grande, n. 325,  
Edificio Cheong Fai, 2 andar "B", Macau

#### USA

INTERBLOCK USA L.C.  
Address: 6900 S Decatur Blvd. Suite 100, Las Vegas,  
NV 89118, USA

#### Latin America

INTERBLOCK Spain S.L. – Argentina Branch  
Regional Office Buenos Aires, Argentina  
Address: Esmeralda 1320, Piso 6° Of. B,  
Buenos Aires 1007, Argentina

#### Europe

INTERBLOCK D.O.O.  
Address: Gorenjska cesta 23,  
1234 Mengeš, Slovenia, Europe

#### Japan

GK INTERBLOCK – Japan Office  
Address: 9th floor TS Tower,  
4-12-3 Higashishinagawa,  
Shinagawa-ku, Tokyo  
140-0002 Japan